

## Tabella di conversione della coppia per Chiavi Idrauliche Dinamometriche

### NS-27

PSI	Ft-lbs	Bar	Nm
1000	3032	69	4111
1200	3606	83	4889
1400	4180	97	5668
1600	4755	110	6446
1800	5329	124	7225
2000	5903	138	8003
2200	6469	152	8771
2400	7035	165	9538
2600	7600	179	10305
2800	8166	193	11072
3000	8732	207	11839
3200	9302	221	12612
3400	9873	234	13386
3600	10443	248	14159
3800	11014	262	14932
4000	11584	276	15706
4200	12137	290	16455
4400	12690	303	17205
4600	13242	317	17954
4800	13795	331	18704
5000	14348	345	19453
5200	14911	359	20217
5400	15474	372	20980
5600	16037	386	21743
5800	16600	400	22507
6000	17163	414	23270
6200	17720	427	24026
6400	18278	441	24781
6600	18835	455	25537
6800	19393	469	26293
7000	19950	483	27049
7200	20510	496	27807
7400	21069	510	28566
7600	21629	524	29325
7800	22188	538	30083
8000	22748	552	30842
8200	23308	565	31601
8400	23868	579	32360
8600	24427	593	33119
8800	24987	607	33878
9000	25547	621	34637
9200	26106	634	35395
9400	26665	648	36153
9600	27225	662	36912
9800	27784	676	37670
10000	28343	689	38428